

# INSTALLATION INSTRUCTIONS

## REMOVE PACKING MATERIALS:

Remove materials, tape and labels before using the freezer.

Do not use sharp instruments, rubbing alcohol, flammable fluids or abrasive cleaners. These can damage the material.


## Clean your freezer before using it:

1. Use a sponge, cloth or paper towel and mild detergent in warm water to clean outside and inside of freezer, door liner and gasket.
2. Rinse and dry thoroughly.

## CHOOSE FREEZER LOCATION:

1. Locate the freezer in a safe place, indoors, away from direct sunlight or heat sources such as a range, dishwasher, laundry equipment, heat vents or radiator.
2. **DO NOT** store flammables such as gasoline near the freezer.
3. Check the strength of the floor. It should hold the weight of a fully loaded freezer.
4. Allow at least 3" (7.5 cm) between top of freezer and the ceiling.
5. Allow at least 1" (2.5 cm) between back of freezer and the wall.
6. Allow 3" (7.5 cm) on each side of the freezer for ease of installation.
7. If the freezer is to be against a wall, you might want to leave extra space on the hinge side so the door can be opened wider.
8. This freezer is designed to operate at a household temperature of 32° to 110° F (0° to 43° C).

## INSTALL FREEZER:



1. Locate the 2 front levelling legs among the packing materials.
2. Screw these legs into the front holes on the bottom of the freezer. The back of the freezer rests on 2 fixed supports.
3. Adjust the 2 front legs so that the front of the freezer is slightly higher than the back. When adjusted properly, the door will swing shut from 10" open.