

WC1500DSS WC400SS

Door reversal instructions

Lay the unit down on its back.

Start with the bottom hinge, remove the Phillips head screws and remove the bottom door hinge.

Once the hinge is removed, proceed by taking the door away from the unit by sliding it down from the top of the unit.

Remove the pivot from the top by unscrewing it.

Replace the pivot on the other side by screwing it in.

Remove the silver cap from the side of the door, and replace in side where the door was attached.

Replace the door by sliding back into place.

Replace the hinge on the opposite side by screwing the screws you had removed in the beginning.

Stand the unit up. DO NOT plug in for 24 hours after unit has been lying down.