



# PGP989—Unpack Your Cooktop


If any installation parts for your gas downdraft cooktop are missing or defective, call GE Parts at 800.626.2002 and we will send replacement parts directly to you.

Please do not call GE Consumer Service to schedule a service call for replacement parts. Thank you and enjoy your new cooktop!


## PARTS INCLUDED (packed below the cooktop)

- Blower assembly
- Mounting nuts (4)  
(10-32 keps—nuts with lock washers attached)
- Blower plenum
- Burner grates (2)
- Reflective tape
- Sheet metal screws (9)  
(8-18 x 3/8")
- Foam gasket tape (9 ft. roll)
- Vent filter
- Vent grille
- Vent grille gasket
- Cleaning cream
- Scrub sponge or scraper  
(on some models)
- Gas pressure regulator & LP Conversion Instructions
- Burner heads (1 small [A], 2 medium [B], 1 large [C])
- Burner caps (1 small [A], 2 medium [B], 1 large [C])
- 120V grounded plug cord  
(attached)


Check to be sure that all packing materials and tape have been removed. This will include tape on control knobs (if applicable), adhesive tape, wire ties, cardboard and protective plastic. Failure to remove these materials could result in damage to the appliance once the appliance has been turned on and surfaces have heated.




Blower assembly and mounting nuts (4)  
(10-32 keps—nuts with lock washers attached)




Blower plenum




Burner grates (2)




Vent filter




Vent grille



Sheet metal screws (9)  
(8-18 x 3/8")




Reflective Tape




Foam gasket tape  
(9 ft. roll)



Cleaning cream  
(WX10X300)




Scrub sponge  
or scraper  
(on some models)




Vent grille  
gasket



**CAUTION:**  
DO NOT LIFT FROM  
VENT OPENING OR  
BUMP GLASS



Gas pressure regulator



**CAUTION:** GLASS IS FRAGILE. DO NOT BUMP EDGE OF GLASS DURING INSTALLATION.

49-80518

06-08 JR



# PGP989—Desempaque su estufa







Si cualquier parte de instalación de su estufa de gas falta o es defectuosa, llame al departamento de partes de GE al 800.626.2002 y le enviaremos las partes de reemplazo directamente.

Por favor, no llame al departamento de Servicio al cliente de GE para programar una llamada de servicio para partes de reemplazo. ¡Gracias y que disfrute su estufa!

## PARTES INCLUIDAS (empacadas debajo de la estufa)



- Ensambladura del soplador
- Tuercas de montaje (4)  
(10-32 tuercas—con sus arandelas de cierre pegadas)
- Pleno del soplador
- Planchas del quemador (2)
- Cinta reflectante
- Tornillos de plancha metálica (9)  
(8-18 x 3/8")
- Cinta de junta de espuma (rollo de 9 pies)
- Filtro del ventilador
- Rejilla de ventilación
- Junta de rejilla de ventilación
- Crema de limpieza
- Esponja de restriegue o raspador (en algunos modelos)
- Regulador de presión de gas et
- Instrucciones para conversión a LP
- Cabezas del quemador (1 pequeña [A], 2 medianas [B], 1 grande [C])
- Tapas del quemador (1 pequeña [A], 2 medianas [B], 1 grande [C])
- Cable de enchufe conectado a tierra 120V (adjunto)

Asegúrese que todos los materiales de empaque y cintas se hayan retirado. Esto incluye cintas sobre las perillas de control (si corresponde), cinta adhesiva, cintas de ajuste, cartón y plástico protector. Si estos materiales no se retiran se puede producir como resultado un daño sobre el electrodoméstico, una vez que el mismo fue encendido y las superficies se calientan.





Filtro del ventilador

Rejilla de ventilación



Regulador de presión de gas



Cabeza del quemador mediana (2)

Tapa del quemador pequeña

Cabeza del quemador pequeña

**PRECAUCIÓN:**  
EL VIDRIO ES FRÁGIL.  
NO CHOQUE LA ESQUINAS DEL VIDRIO DURANTE LA INSTALACIÓN.

