



# Electrolux

## Factory Parts Catalog

Product No.	E48GC76EPS
Series	48" slide-in
Color	stainless
Market	North America
Wiring Diagram	100213
Owner's Guide	5995447090
Installation Instructions	5995447108

# Electrolux

Electrolux Major Appliances  
North & Latin America  
P.O. BOX 212378  
AUGUSTA, GA 30917

Publication No.  
**5995458709**  
06/01/16  
(EN/SERVICE/ECL)  
377

## GAS SLIDE-IN COOK-TOP

Model No.  
E48GC76E

Copyright © 2005 Electrolux Home Products, Inc.  
All rights reserved.



---

**COOK TOP**


---

POS. NO	PART NO.	DESCRIPTION
1	5304454001	Trim, rear
2	5304454002	Trim, side, RH
3	5304454003	Trim, side, LH
4	5304446031	Bezel, burner knob
5	5304454004	Maintop, spill tray
8	5304446028	Nut, burner head, brass
9	5304452881	Rings, burner, set of 6
10	5304452880	Caps, burner, set of 6
11 #	5304453979	Ignitor Assembly, burner, w/jacket
11*	5304446002	Jacket, ignitor wire
15 #	5304452825	Burner Head Assy, "B", 8500 BTU, w/ignitor
16 #	5304452826	Burner Head Assy, "D", 14000 BTU, w/ignitor
19	5304454006	Panel, control, stainless
20A	5304452878	Grate, burner, 14"
34	5304452454	Screw, #8 x .375"
36	5304452800	Knob, top burner
69	5304452792	Screw, mounting
*	5304454005	Mounting Kit, to cabinet



**BURNER**

POS. NO	PART NO.	DESCRIPTION
1 #	5304454007	Tubing Assembly, burner, left front
2 #	5304454008	Tubing Assembly, burner, left rear
3 #	5304454009	Tubing Assembly, burner, right front
4 #	5304454010	Tubing Assembly, burner, right rear
5	5304446019	Screw, phil TRS, #8-3/8, (18)
6 #	5304454011	Valve Assembly, w/switch, (4)
7 #	5304454012	Valve Assembly, w/switch, (2)
10 #	5304446014	Switch, ignitor
12 #	5304446036	Regulator, pressure
13 #	5304446001	Base, burner, (6)
14 #	5304454014	Manifold Assembly, w/valves
16	5304446017	Bushing, strain relief
17	5304446023	Screw, ignitor switch
18 #	5304446005	Cord, power supply
19 #	5304446143	Module, assembly, ignitor spark
19*	5304454013	Insulation
20 #	5304454015	Harness, wiring, main
21 #	5304454016	Harness, wiring, ignitors
22	5304446021	Screw, phil pan, #8-32 x 1/2, (3)
24	5304446015	Nut, hex keps, #8-32
25	5304446020	Screw, phil pan, #8-3/8
26	5304446016	Washer, nylon
28 #	5304454017	Tubing Assembly, burner, center rear
29 #	5304454018	Tubing Assembly, burner, center front

### WIRING DIAGRAM

