

# Important Information About Your New Washer...

Thank you for purchasing a Speed Queen topload washer! To register your product, go to [www.speedqueen.com](http://www.speedqueen.com).

## The Normal Eco Cycle

The Normal Eco Cycle is designed to meet the U.S. Department of Energy requirements for energy usage and water consumption. You will notice that this cycle uses less hot water to save energy and a spray rinse to reduce water consumption.




### How does it work?

- The washer begins filling with cold water and a small amount of hot water, depending on the temperature selected.
- The washer finishes filling with all cold water and goes into agitation.
- During the rinse portion of the cycle, the wash tub won't fill with water. Instead, there is a spray rinse.

These functions are unique to the Normal Eco Cycle. All other cycles have no temperature restriction and utilize a full tub rinse.

## Blue Light Blinking

The blue light blinking in the lower right corner of the display is a power saving feature that keeps the control in an idle mode at a very low power consumption.



Refer to the washer's User's Guide or go to [www.speedqueen.com](http://www.speedqueen.com) for more product information.

Part No. 203817  
May 2016