




## **30" ELECTRIC FREESTANDING SELF CLEAN RANGE**

### **MODELS:**

ACR4303MFB3 (Black)  
ACR4303MFW3 (White)


# COOKTOP PARTS



# COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	4	3195060	Hinge, Cooktop	10	W10306542	Bracket, Anti-Tip
	W11235898	User Instructions	5	3196178	Screw			FOLLOWING PARTS NOT ILLUSTRATED
	W11241246	Wiring Diagram	6	3195812	Rod, Support			
	W11047681	Instructions, Installation	7	7101P485-60	Screw, Anti-Tip Kit		W11134841	Harness, Main
2	W10196406	Bowl, Drip (6") (Right Front and Left Rear)	8	3196154	Screw		W11134595	Harness, Cooktop
	W10196405	Bowl, Drip (8") (Left Front and Right Rear)	9	W11199519	Element, Coil Heating (1300W)  (Right Front and Left Rear)		W10281322	Kit, Bare Wire Adapter Block
3		Cooktop		W11199518	Element, Coil Heating (2150W)  (Left Front and Right Rear)			
	3186233	Black						
	3186231	White						


# CONTROL PANEL PARTS



# CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	4	3148953	Switch, Infinite (Green)	8	W10134247	Shield, Heat
	W11130372	Black (Left)			(Right Front and Left Rear)	9	3196165	Screw
	W11130379	Black (Right)				10	8272473	Cover, Upper Rear
	W11130371	White (Left)		3148951	Switch, Infinite	11	W10525121	Bracket, Console Mounting
	W11130378	White (Right)			(Left Front and Right Rear)	12		Control, Electronic
2	W10695491	Bracket, Control	5	3196169	Screw		W11204487	Black
3		Panel, Control	6	3400882	Screw		W10837800	White
	W11157010	Black	7		Knob, Infinite	13	3196178	Screw
	W11157009	White		W10844801	Black	14	3196200	Clip, Spring
				W10844800	White			


# CHASSIS PARTS



# CHASSIS PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11222267	Tube, Vent	15	W10390008	Assembly, Base Rail (Left)	26	3196567	Screw
2	W10209613	Box, Burner				27	W10181986	Sensor, Oven
3		Panel, Side		W10390007	Assembly, Base Rail (Right)	28	3196165	Screw
	W10162245	Black				29	3186034	Bracket, Service
	W10575396	White	16	W10058460	Foot, Leveling	30	3196178	Screw
4	W10268578	Rack, Oven	17	W10289077	Receiver, Hinge	31	3400016	Screw
5	W10129032	Seal, Door	18	3196172	Screw	32	W10326122	Cover, Terminal Block
6	W10308476	Element, Broil	19	W10404688	Clip, Oven Support	33	W10910404	Counterweight
7	W11022836	Element, Bake	20	W10674705	Glide, Drawer Front	34	W11034869	Screw
8	3400029	Nut	21	W10245259	Block, Terminal			FOLLOWING PARTS NOT ILLUSTRATED
9	3196548	Fuse, Thermal	22		Back, Main (Not Serviced)			
10	3196169	Screw					8273263	Insulation, Wrap
11	W10341186	Assembly, Front Foot	23	3196174	Screw		8272611	Insulation, Back
12	W10067840	Screw	24	W11175594	Assembly, Light			
13	8054068	Retainer, Insulation	25	W10571723	Bulb, Halogen 40 Watts			
14	W10137382	Clip, Panel						

# DOOR PARTS






# DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Trim, Top	9	9761505	Retainer, Insulation	14		Trim, Lower
	W10310922	Black	10	W10299225	Hinge, Active		8523177	Black
	W10310920	White	11		Glass, Outer		8523175	White
2	W10168559	Screw		W10831686	Black	15	W10031790	Screw
3		Handle, Door		W10851723	White	16	W10200660	Screw
	W10323589	Black	12		Trim, Side	17	W10544179	Strap, Door
	W10323588	White		W10746435	Black (Right)			
4	9761344	Liner, Door		W10746436	Black (Left)			
5	W10137382	Clip, Panel		8523166	White (Right)			
6	W10620754	Glass, Inner		8523172	White (Left)			
7	W10299227	Hinge, Door (Passive)	13	W10327235	Screw			
8	3196165	Screw						

# DRAWER PARTS



# DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	3196165	Screw
2	W10688022	Drawer, Storage
3	W10462912	Bracket, Mounting Drawer

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4		Rivet, Push
	3196813	Black
	3196814	White

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
5		Panel, Drawer Front
	W11123900	Black
	W11123901	White
6	W10674708	Glide, Drawer Rear

# OPTIONAL PARTS

## REFINISHING MATERIAL

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

## PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	511873	White Porcelain (2 oz.)

## PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

## INSULATION

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2" x 24" x 120")
	240132	Insulation (2-1/2" x 22" x 120")

## PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	206922	Primer (White)

## ACCESSORY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	241430	Aluminum Foil
	3184478	Cleaner, Glass
	4396923	Grid, Broiler Pan and