

DENON AVR/AVC control protocol

Ver. 4.0

Application model : AVR-3805/AVC-3890

Application terminal : RS-232C

Connector specification

Connector type : DB-9pin female type, slave straight connection (DCE type)

(1pin : GND , 2pin : TxD , 3pin : RxD , 5pin : Common(GND) , 4,6,7,8,9pin : NC)

Communication format :

Synchronous system	: Tone step synchronization
communication system	: A half duplex
Communication speed	: 9600bps
Character length	: 8 bits
Parity control	: None
Start bit	: 1 bit
Stop bit	: 1 bit
Communication procedure	: Non procedural
Communication data length	: 135 bytes (maximum)

Protocol specification

The following three data forms is defined.

- COMMAND** : The message sent to a system(AVR/AVC) from a controller(Touch Panel etc.)
A command to a system is given from a controller.
- EVENT** : The message sent to a controller(Touch Panel etc.) from a system(AVR/AVC)
The result is sent, when a system is operated directly and a state changes.
*The form of **EVENT** presupposes that it is the same as that of **COMMAND**.
Refer to the following table for the contents of **COMMAND and **EVENT**.
- RESPONSE** : The message sent to a controller(Touch Panel etc.) from a system(AVR/AVC)
if the 'request command' (**COMMAND**+?**CR**(0x0D)) has came from a controller.
The **RESPONSE** should be sent within 200ms of receiving the **COMMAND**.
*The form of **RESPONSE** presupposes that it is the same as that of **EVENT**.

Basic specification : The command by ASCII CODE, parameter expression

*ASCII CODE which can be used is from 0x20 to 0x7F : the alphabet and the number of 0-9 , and space (0x20) , Some signs ,
AND carriage return(0x0D)--- It is used only as a pause sign.

Command structure : **COMMAND** + **PARAMETER** + **CR**(0x0D)

COMMAND : ASCII CODE of 2 characters

ex. **SI** : Select Input source
 MS : surround Mode Setting
 MV : Master Volume setting
 PW : system PoWer setting

PARAMETER : ASCII CODE (up to 25 characters)

ex. **DVD** : function name
 CDR/TAPE-1 : function name
 THX SURROUND EX : surround mode name
 SUPER STADIUM : surround mode name

*Special Parameter--- ? : for request command

The example of a command * <CR> is the meaning of 0x0D.

SIDVD<CR> : Select Input source DVD

MSTHX SURROUND EX<CR> : surround Mode Set to THX SURROUND EX

MVUP<CR> : Master Volume UP

PWON<CR> : system PoWer ON

PWSTANDBY<CR> : system PoWer STANDBY

SI?<CR> : Request command for now playing input source >> Return **RESPONSE** 'SI***<CR>'

Others

- A) **COMMAND** is receivable also during transmission of **EVENT**.
- B) Since CHANNEL VOLUME changes simultaneously when the SURROUND MODE changes, the value of the channel volume of all channels returns as **EVENT**.
- C) CHANNEL VOLUME returns the data of ALL channels by the present SURROUND MODE also including an intact channel. In this case, the data of an intact channel is set to "50".
- D) Since SURROUND MODE changes simultaneously when the INPUT source changes, the SURROUND MODE (and also the value of the channel volume of all channels , It described in B)) returns as **EVENT**.
- E) When SURROUND MODE is the same in between INPUT source change before and after, **EVENT** of SURROUND MODE and CHANNEL VOLUME does NOT return.
- F) Although **EVENT** of SURROUND MODE returns when the present SURROUND MODE is set up again, CHANNEL VOLUME does NOT return.
- G) When SURROUND MODE is changed, before returning SURROUND MODE after change as **EVENT**, the present SURROUND MODE is returned.
- H) The **RESPONSE** should be sent as opposed to the request command by all the commands with which an **EVENT** exists , not need to the another request commands(ex. SV command).
- I) The **PARAMETER** (with **COMMAND** and **RESPONSE, EVENT**) of minimum level of MASTER VOLUME defines "99".

J) If the MASTER VOLUME & CHANNEL VOLUME set with 0.5dB step, the **PARAMETER** (with **COMMAND** and **RESPONSE, EVENT**) defines three ASCII characters as bellows.

ex. MASTER VOLUME = +1.0dB :	MV81<CR>
+0.5dB :	MV805<CR>
0dB :	MV80<CR>
-0.5dB :	MV795<CR>
-1.0dB :	MV79<CR>
-79.5dB :	MV005<CR>
-80.0dB :	MV00<CR>
---	MV99<CR>

* At the **.0dB step, only uses two ASCII characters as **PARAMETER**, same as usual.

COMMAND and PARAMETER list

COMMAND	PARAMETER	function	example
PW	ON	POWER ON/STANDBY change	PWON<CR>
	STANDBY		PWSTANDBY<CR>
MV	UP	MASTER VOLUME UP/DOWN , direct change to **dB **:00 to 99 by ASCII , 80=0dB, 99=---(MIN)	MVUP<CR>
	DOWN		MVDOWN<CR>
	**		MV80<CR>
CV	FL UP	CHANNEL VOLUME UP/DOWN , direct change to **dB ---FRONT Lch	CVFL UP<CR>
	FL DOWN		CVFL DOWN<CR>
	FL **		CVFL 50<CR>
	FR UP	---FRONT Rch	CVFR UP<CR>
	FR DOWN		CVFR DOWN<CR>
	FR **		CVFR 50<CR>
	C UP	---CENTERch	CVC UP<CR>
	C DOWN		CVC DOWN<CR>
	C **		CVC 50<CR>
	SW UP	---SUBWOOFERch	CVSW UP<CR>
	SW DOWN		CVSW DOWN<CR>
	SW **		CVSW 50<CR>
	SL UP	---SURROUND Lch	CVSL UP<CR>
	SL DOWN		CVSL DOWN<CR>
	SL **		CVSL 50<CR>
	SR UP	---SURROUND Rch	CVSR UP<CR>
	SR DOWN		CVSR DOWN<CR>
	SR **		CVSR 50<CR>
	SBL UP	---SURROUND BACK Lch (SBch 2SP)	CVSBL UP<CR>
	SBL DOWN		CVSBL DOWN<CR>
	SBL **		CVSBL 50<CR>
	SBR UP	---SURROUND BACK Rch (SBch 2SP)	CVSBR UP<CR>
	SBR DOWN		CVSBR DOWN<CR>
	SBR **		CVSBR 50<CR>

MV , CV COMMAND : "*" parameter uses two or three ASCII characters. (see page4 J) section)

COMMAND	PARAMETER	function	example
CV	SB UP	---SURROUND BACKch (SBch 1SP) ** : 38 to 62 by ASCII , 50=0dB	CVSB UP<CR>
	SB DOWN		CVSB DOWN<CR>
	SB **		CVSB 50<CR>
MU	ON	OUTPUT MUTE ON/OFF change	MUON<CR>
	OFF		MUOFF<CR>
SI	PHONO	Select INPUT source	SIPHONO<CR>
	CD		SICD<CR>
	TUNER		SITUNER<CR>
	DVD		SIDVD<CR>
	VDP		SIVDP<CR>
	TV		SITV<CR>
	DBS/SAT		SIDBS/SAT<CR>
	VCR-1	---Select DBS function at AVR-3805 ---Invalid at AVR-3805	SIVCR-1<CR>
	VCR-2		SIVCR-2<CR>
	VCR-3		SIVCR-3<CR>
	V.AUX		SIV.AUX<CR>
	CDR/TAPE1	---Select CDR/TAPE function at AVR-3805	SICDR/TAPE1<CR>
	MD/TAPE2	---Invalid at AVR-3805	SIMD/TAPE2<CR>
ZM	ON	MAIN-ZONE ON/OFF change at AVR-3805	ZMON<CR>
Z1	OFF	MULTI ZONE-3 mode set , and select source at AVR-3805 ---The name of PARAMETER is the same as that of the time of SI COMMAND. MULTI ZONE-3 mode cancel at AVR-3805 MULTI ZONE-3 VOLUME UP/DOWN , direct change to ***dB at AVR-3805 ** : 00 to 99 by ASCII , 80=0dB, 99=--- (MIN) MULTI ZONE-3 ON/OFF change at AVR-3805	ZMOFF<CR>
	PHONO		Z1PHONO<CR>
	CDR/TAPE1		Z1MD/TAPE2<CR>
	SOURCE		Z1SOURCE<CR>
	UP		Z1UP<CR>
	DOWN		Z1DOWN<CR>
	**		Z180<CR>
	ON		Z1ON<CR>
	OFF		Z1OFF<CR>

CV COMMAND : "*" parameter uses two or three ASCII characters. (see page4 J) section)

COMMAND	PARAMETER	function	example
Z2	PHONO CDR/TAPE1	MULTI ZONE-2 mode set , and select source at AVR-3805 ---The name of PARAMETER is the same as that of the time of SI COMMAND.	Z2PHONO<CR> Z2MD/TAPE2<CR>
	SOURCE	MULTI ZONE-2 mode cancel	Z2SOURCE<CR>
	UP	MULTI ZONE-2 VOLUME UP/DOWN , direct change to ***dB	Z2UP<CR>
	DOWN		Z2DOWN<CR>
	**	** : 00 to 99 by ASCII , 80=0dB, 99=---(MIN)	Z280<CR>
	ON	MULTI ZONE-2 ON/OFF change at AVR-3805	Z2ON<CR>
	OFF		Z2OFF<CR>
SR	PHONO CDR/TAPE1	REC SELECT mode set , and select source ---The name of PARAMETER is the same as that of the time of SI COMMAND.	SRPHONO<CR> SRMD/TAPE2<CR>
	SOURCE	REC SELECT mode cancel	SRSOURCE<CR>
SV	DVD	VIDEO SELECT mode set , and select source	SVDVD<CR>
	VDP		SVVDP<CR>
	TV		SVTV<CR>
	DBS/SAT		SVDBS/SAT<CR>
	VCR-1	---Select DBS function at AVR-3805	SVVCR-1<CR>
	VCR-2		SVVCR-2<CR>
	VCR-3		SVVCR-3<CR>
	V.AUX		SVV.AUX<CR>
	SOURCE	VIDEO SELECT mode cancel	SVSOURCE<CR>
SD	AUTO	set DIGITAL INPUT AUTO mode	SDAUTO<CR>
	PCM	set DIGITAL INPUT force PCM mode	SDPCM<CR>
	DTS	set DIGITAL INPUT force DTS mode	SDDTS<CR>
	RF	---Invalid at AVR-3805	SDRF<CR>
	ANALOG	set force ANALOG INPUT mode	SDANALOG<CR>
	EXT.IN-1	set EXT.IN-1 mode ---Set EXT.IN mode at AVR-3805	SDEXT.IN-1<CR>
	EXT.IN-2	set EXT.IN-2 mode ---Invalid at AVR-3805	SDEXT.IN-2<CR>

EVENT	PARAMETER	function	example
MS	DIRECT	SURROUND mode set	MSDIRECT<CR>
	PURE DIRECT		MSPURE DIRECT<CR>
	STEREO		MSSTEREO<CR>
	MULTI CH IN		MSMULTI CH IN<CR>
	MULTI CH DIRECT		MSMULTI CH DIRECT<CR>
	MULTI CH PURE D		MSMULTI CH PURE D<CR>
	DOLBY PRO LOGIC	All are received as "DOLBY SURROUND" , the surround mode which changed return as EVENT .	MSDOLBY PRO LOGIC<CR>
	DOLBY PL2		MSDOLBY PL2<CR>
	DOLBY PL2x		MSDOLBY PL2X<CR>
	DOLBY DIGITAL		MSDOLBY DIGITAL<CR>
	DOLBY D EX		MSDOLBY D EX<CR>
	DTS NEO:6	All are received as "DTS SURROUND" ,	MSDTS NEO:6<CR>
	DTS SURROUND		MSDTS SURROUND<CR>
	DTS ES DSCRT6.1		MSDTS ES DSCRT6.1<CR>
	DTS ES MTRX6.1		MSDTS ES MTRX6.1<CR>
	DOLBY H/P	---Invalid at AVR-3805	MSDOLBY H/P<CR>
	DTS+DOLBY H/P	---Invalid at AVR-3805	MSDTS+DOLBY H/P<CR>
	HOME THX CINEMA	---Invalid at AVR-3805	MSHOME THX CINEMA<CR>
	THX5.1	---Invalid at AVR-3805	MSTHX5.1<CR>
	THX U2 CINEMA	---Invalid at AVR-3805	MSTHX U2 CINEMA<CR>
	THX MUSIC MODE	---Invalid at AVR-3805	MSTHX MUSIC MODE<CR>
	THX6.1	---Invalid at AVR-3805	MSTHX6.1<CR>
	THX SURROUND EX	---Invalid at AVR-3805	MSTHX SURROUND EX<CR>
	WIDE SCREEN		MSWIDE SCREEN<CR>
	5CH STEREO	Both are received as "5CH/7CH STEREO" , the surround mode which changed return as EVENT .	MS5CH STEREO<CR>
	7CH STEREO		MS7CH STEREO<CR>
	SUPER STADIUM		MSSUPER STADIUM<CR>
	ROCK ARENA		MSROCK ARENA<CR>
	JAZZ CLUB		MSJAZZ CLUB<CR>
	CLASSIC CONCERT		MSCLASSIC CONCERT<CR>
	MONO MOVIE		MSMONO MOVIE<CR>
	MATRIX		MSMATRIX<CR>
	VIDEO GAME		MSVIDEO GAME<CR>
	VIRTUAL		MSVIRTUAL<CR>

EVENT	PARAMETER	function	example
MS	MPEG2 AAC	---Invalid at AVR model	MSMPEG2 AAC<CR>
	AAC+DOLBY EX	---Invalid at AVR model	MSAAC+DOLBY EX<CR>
PS	TONE DEFEAT ON	PARAMETER setting	PSTONE DEFEAT ON<CR>
	TONE DEFEAT OFF	TONE DEFEAT ON/OFF	PSTONE DEFEAT OFF<CR>
	SB:MTRX ON	SURROUND BACK SP MODE set	PSSB:MTRX ON<CR>
	SB:NON MTRX	---	PSSB:NON MTRX<CR>
	SB:PL2xCINEMA	---MTRX ON = SURR.EX ON = DSCRT ON (@THX) (@ES DSCRT)	PSSB:PL2X CINEMA<CR>
	SB:PL2xMUSIC		PSSB:PL2X MUSIC<CR>
	SB:OFF		PSSB:OFF<CR>
	CINEMA EQ.ON	CINEMA EQ. ON/OFF	PSCINEMA EQ.ON<CR>
	CINEMA EQ.OFF		PSCINEMA EQ.OFF<CR>
	MODE : MUSIC	CINEMA / MUSIC / GAME / PL mode change	PSMODE : MUSIC<CR>
	MODE : CINEMA	(This parameter can change DOLBY PL2,PL2x,NEO:6 mode.)	PSMODE : CINEMA<CR>
	MODE : GAME	---SB=ON: PL2x mode / SB=OFF: PL2 mode	PSMODE : GAME<CR>
	MODE : PRO LOGIC	--- GAME can change DOLBY PL2 & PL2x mode	PSMODE : PRO LOGIC<CR>
		--- PL can change ONLY DOLBY PL2 mode	
	ROOM EQ:NORMAL	ROOM EQ mode direct change	PSROOM EQ:NORMAL<CR>
	ROOM EQ:FRONT		PSROOM EQ:FRONT<CR>
	ROOM EQ:FLAT		PSROOM EQ:FLAT<CR>
	ROOM EQ:MANUAL		PSROOM EQ:MANUAL<CR>
	ROOM EQ:OFF		PSROOM EQ:OFF<CR>
TF	UP	TUNER Frequency UP/DOWN , direct change	TFUP<CR>
	DOWN		TFDOWN<CR>
	***** (6 digits)	--- ****.* kHz at AM band (>050000 is AM.) ****.* MHz at FM band (<050000 is FM.)	TF105000<CR> (1050.00kHz at AM)
TP	UP	TUNER PRESET CH UP/DOWN , direct change to No.**	TPUP<CR>
	DOWN **(PRESET No.)		TPDOWN<CR> TPA1<CR> (PRESET No."A1")
TM	AM	TUNER BAND , MODE Select ---Band set to AM	TMAM<CR>
	FM	---Band set to FM	TMFM<CR>
	AUTO	---Tuning mode set to AUTO mode	TMAUTO<CR>
	MANUAL	---Tuning mode set to MANUAL mode	TMMANUAL<CR>

TF, TP, TM **COMMAND** : '*' parameters can NOT operate when INPUT source isn't TUNER.

EVENT(or RESPONSE) and PARAMETER list

EVENT	PARAMETER	function	example	*RES.
PW	ON	POWER ON/STANDBY change	PWON<CR>	
	STANDBY		PWSTANDBY<CR>	
MV	**	MASTER VOLUME change , **:00 to 98 by ASCII 98 = +18dB(MAX) 80 = 0dB 00 = -80dB 99 = --- (MIN)	MV80<CR>	
CV	FL **	CHANNEL VOLUME change , **:38 to 62 by ASCII 62 = +12dB(MAX) 50 = 0dB 38 = -12dB(MIN) 00 = OFF (define ONLY SWch in DIRECT mode.) (at SBch 2SP) (at SBch 2SP) (at SBch 1SP)	CVFL 50<CR>	
	FR **		CVFR 50<CR>	
	C **		CVC 50<CR>	
	SW **		CVSW 50<CR>	
	SL **		CVSL 50<CR>	
	SR **		CVSR 50<CR>	
	SBL **		CVSBL 50<CR>	
	SBR **		CVSBR 50<CR>	
	SB **		CVSB 50<CR>	
MU	ON	OUTPUT MUTE ON/OFF change	MUON<CR>	
	OFF		MUOFF<CR>	
SI	PHONO	INPUT source change ---Select DBS function at AVR-3805 ---Invalid at AVR-3805 ---Select CDR/TAPE function at AVR-3805 ---Invalid at AVR-3805	SIPHONO<CR>	
	CD		SICD<CR>	
	TUNER		SITUNER<CR>	
	DVD		SIDVD<CR>	
	VDP		SIVDP<CR>	
	TV		SITV<CR>	
	DBS/SAT		SIDBS/SAT<CR>	
	VCR-1		SIVCR-1<CR>	
	VCR-2		SIVCR-2<CR>	
	VCR-3		SIVCR-3<CR>	
	V.AUX		SIV.AUX<CR>	
	CDR/TAPE1		SICDR/TAPE1<CR>	
	MD/TAPE2		SIMD/TAPE2<CR>	

*RES. : NOT returns '?' parameters as **RESPONSE**.

MV , CV **COMMAND** : "*" parameter uses two or three ASCII characters. (see page4 J) section)

EVENT	PARAMETER	function	example	*RES.
ZM	ON	MAIN-ZONE ON/OFF change	ZMON<CR>	
	OFF		ZMOFF<CR>	
Z1	PHONO CDR/TAPE1	MULTI ZONE-3 source change ---The name of PARAMETER is the same as that of the time of SI COMMAND.	Z1PHONO<CR> Z1MD/TAPE2<CR>	
	SOURCE	MULTI ZONE-3 mode cancel	Z1SOURCE<CR>	
	**	MULTI ZONE-3 VOLUME change , **:00 to 99 by ASCII 98 = +18dB(MAX) 80 = 0dB 10 = -70dB 99 = --- (MIN)	Z180<CR>	?
	ON	MULTI ZONE-3 ON/OFF change	Z1ON<CR>	?
	OFF		Z1OFF<CR>	?
Z2	PHONO CD/TAPE1	MULTI ZONE-2 source change ---The name of PARAMETER is the same as that of the time of SI COMMAND.	Z2PHONO<CR> Z2MD/TAPE2<CR>	
	SOURCE	MULTI ZONE-2 mode cancel	Z2SOURCE<CR>	
	**	MULTI ZONE-2 VOLUME change , **:00 to 99 by ASCII 98 = +18dB(MAX) 80 = 0dB 10 = -70dB 99 = --- (MIN)	Z180<CR>	?
	ON	MULTI ZONE-2 ON/OFF change	Z2ON<CR>	?
	OFF		Z2OFF<CR>	?
SR	PHONO CD/TAPE1	REC SELECT source change ---The name of PARAMETER is the same as that of the time of SI COMMAND.	SRPHONO<CR> SRMD/TAPE2<CR>	
	SOURCE	REC SELECT mode cancel	SRSOURCE<CR>	

EVENT	PARAMETER	function	example	*RES.
TF	***** (6 digits)	TUNER Frequency change --- ****.* kHz at AM band ****.* MHz at FM band	TF105000<CR> (1050.00kHz at AM)	
TP	**(PRESET No.)	TUNER PRESET change to No.**	TPA1<CR> (PRESET No. "A1")	
TM	AM	TUNER BAND , MODE change ---Band set to AM	TMAM<CR>	?
	FM	---Band set to FM	TMFM<CR>	?
	AUTO	---Tuning mode set to AUTO mode	TMAUTO<CR>	
	MANUAL	---Tuning mode set to MANUAL mode	TMMANUAL<CR>	

*RES. : NOT returns '?' parameters as **RESPONSE**.

<i>EVENT</i>	<i>PARAMETER</i>	<i>function</i>	<i>example</i>	<i>*RES.</i>
MS	DIRECT	SURROUND mode change	MSDIRECT<CR>	
	PURE DIRECT		MSPURE DIRECT<CR>	
	STEREO		MSSTEREO<CR>	
	MULTI CH IN		MSMULTI CH IN<CR>	
	MULTI CH IN +PL2x CINEMA		MSM CH IN+PL2X C<CR>	
	MULTI CH IN +PL2x MUSIC		MSM CH IN+PL2X M<CR>	
	MULTI CH DIRECT		MSMULTI CH DIRECT<CR>	
	MULTI CH DIRECT +PL2x CINEMA		MSM CH DRCT+PL2X C <CR>	
	MULTI CH DIRECT +PL2x MUSIC		MSM CH DRCT+PL2X M <CR>	
	MULTI CH PURE D		MSMULTI CH PURE D<CR>	
	MULTI CH PURE D +PL2x CINEMA		MSM CH PURE D+PL2X C <CR>	
	MULTI CH PURE D +PL2x MUSIC		MSM CH PURE D+PL2X M <CR>	
	DOLBY PRO LOGIC		MSDOLBY PRO LOGIC<CR>	
	DOLBY PL2 CINEMA		MSDOLBY PL2 C<CR>	
	DOLBY PL2 MUSIC		MSDOLBY PL2 M<CR>	
	DOLBY PL2 GAME		MSDOLBY PL2 G<CR>	
	DOLBY PL2x CINEMA		MSDOLBY PL2X C<CR>	
	DOLBY PL2x MUSIC		MSDOLBY PL2X M<CR>	
	DOLBY PL2x GAME		MSDOLBY PL2X G<CR>	
	DOLBY DIGITAL		MSDOLBY DIGITAL<CR>	
	DOLBY D EX		MSDOLBY D EX<CR>	
	DOLBY D +PL2x CINEMA		MSDOLBY D+PL2X C<CR>	
	DOLBY D +PL2x MUSIC		MSDOLBY D+PL2X M<CR>	

<i>EVENT</i>	<i>PARAMETER</i>	<i>function</i>	<i>example</i>	<i>*RES.</i>
	DTS NEO:6 CINEMA		MSDTS NEO:6 C<CR>	
	DTS NEO:6 MUSIC		MSDTS NEO:6 M<CR>	
	DTS SURROUND		MSDTS SURROUND<CR>	
	DTS ES DSCRT6.1		MSDTS ES DSCRT6.1<CR>	
	DTS ES MTRX6.1		MSDTS ES MTRX6.1<CR>	
	DTS+PL2x CINEMA		MSDTS+PL2X C<CR>	
	DTS+PL2x MUSIC		MSDTS+PL2X M<CR>	
	DOLBY H/P	---Invalid at AVR-3805	MSDOLBY H/P<CR>	
	DTS+DOLBY H/P	---Invalid at AVR-3805	MSDTS+DOLBY H/P<CR>	
	HOME THX CINEMA	---Invalid at AVR-3805	MSHOME THX CINEMA<CR>	
	THX5.1	---Invalid at AVR-3805	MSTHX5.1<CR>	
	THX U2 CINEMA	---Invalid at AVR-3805	MSTHX U2 CINEMA<CR>	
	THX MUSIC MODE	---Invalid at AVR-3805	MSTHX MUSIC MODE<CR>	
	THX6.1	---Invalid at AVR-3805	MSTHX6.1<CR>	
	THX SURROUND EX	---Invalid at AVR-3805	MSTHX SURROUND EX<CR>	
	WIDE SCREEN		MSWIDE SCREEN<CR>	
	5CH STEREO		MS5CH STEREO<CR>	
	7CH STEREO		MS7CH STEREO<CR>	
	SUPER STADIUM		MSSUPER STADIUM<CR>	
	ROCK ARENA		MSROCK ARENA<CR>	
	JAZZ CLUB		MSJAZZ CLUB<CR>	
	CLASSIC CONCERT		MSCLASSIC CONCERT<CR>	
	MONO MOVIE		MSMONO MOVIE<CR>	
	MATRIX		MSMATRIX<CR>	
	VIDEO GAME		MSVIDEO GAME<CR>	
	VIRTUAL		MSVIRTUAL<CR>	
	MPEG2 AAC	---Invalid at AVR model	MSMPEG2 AAC<CR>	
	AAC+DOLBY EX	---Invalid at AVR model	MSAAC+DOLBY EX<CR>	
	AAC+PL2x CINEMA	---Invalid at AVR model	MSAAC+PL2X C<CR>	
	AAC+PL2x MUSIC	---Invalid at AVR model	MSAAC+PL2X M<CR>	

EVENT	PARAMETER	function
PS	ROOM EQ:NORMAL	ROOM EQ mode change
	ROOM EQ:FRONT	
	ROOM EQ:FLAT	
	ROOM EQ:MANUAL	
	ROOM EQ:OFF	

example	*RES.
PSROOM EQ:NORMAL<CR>	?
PSROOM EQ:FRONT<CR>	?
PSROOM EQ:FLAT<CR>	?
PSROOM EQ:MANUAL<CR>	?
PSROOM EQ:OFF<CR>	?

*RES. : NOT returns '?' parameters as **RESPONSE**.